

Questions about Lemote laptop

Question 1

I'm luck winner of the GNOME summit event at May 24, 2013 Seoul, Korea
I'm Korean and my name is Jun, Sangdo
My email is sebuls@gmail.com
I'm a public servant and work in datacenter of Seoul.
I' using this netbook in my study linux and surfing information of free/open source software.

I have some problems.
I can see Hanguk(Korean letter) with this netbook, but I can't write Hanguk with that.
I can't boot from usb.(I have bootable usb but can't boot with that netbook)

I tried to change some configuration to write Hanguk.
But...
Now, I can't login this netbook.(Perhaps I broke some settings)
Can I recover this netbook to initial status? How?
Can I install ubuntu at this netbook?(I have bootable ubuntu 12.04 installation USB. But I can't boot netbook)

Anyway, I'm happy since I get that netbook.

Thanks. Have a nice day. Good bye.

Question 2

Hello. I have some questions.

<http://www.lemote.com/en/products/Notebook/2010/0310/112.html>

GNU/Linux OS and free free software
The word free appears twice. Is it typo ?

The usage of the Between left Ctrl and Alt of that netbook?

I broke some settings and could not login that. So I installed debian.
Now, I can login that. But I cannot run X window.
Any hints ?

=====

Question 3

=====

I have a notebook 8089D <http://www.lemote.com/en/products/Notebook/2010/0310/112.html>

I read <http://wiki.debian.org/DebianYeeloong/HowTo/Install> and install debian as follows.

1. Format the USB disk with ext2 and add the required d-i files
2. Start with Yeeloong powered off and no USB sticks installed.
3. Put USB stick in left USB port next to VGA port.
4. Power on Yeeloong.
5. Press 'Del' lots.
6. Should get into PMON> prompt.
7. Delete any extra characters.
8. Type:

```
bl -d ide (usb0,0)/boot.cfg
```

I can use console.

But I cannot use X windows.

When I use lightdm I can input user id and password.

Then only an arrow appears. No menu appears, No icon appears.

How can I solve this problem ?